

## Sample Pick Up:

---



**1** When the sample box is ready, select “Ready for Pickup” on the last email from us or call 502.569.3676 and leave a message, including your address.

**2** Place the box with the samples outside your home, preferably near front door or on porch in an area that can be easily seen from the street.

**3** The box will be picked up within five days.



**Our water quality team** will be in touch within four weeks with your sample results. If you have any questions about this process and would like to speak to someone directly, please call 502.569.3676.



# Water Quality Lead Test Kit

---

Please read the following instructions carefully before collecting your sample or scan the QR code for video instructions.



## Before Sampling:

**1** Do not use the water in your home for at least six hours prior to collecting samples (this includes flushing the toilet, showering, etc.). Take the samples first thing in the morning or when returning from work if no one is home while you are away.



**2** Select an indoor COLD water faucet to use, preferably in the kitchen, which does not have a filter, water softener, or any other home treatment device. Do not remove any screens or aeration devices.



**3** Line up all six numbered containers and remove the lids when ready to collect the samples.

**2** Fill container No. 2 without allowing any water to go to the drain. While filling container No. 2, grab container No. 3 and repeat these steps for containers No. 3, No. 4 and No. 5 - Fifth Liter.



**3** After filling container No. 5 - Fifth Liter, continue running the COLD water for three additional minutes and then fill container No. 6 - Flush.



**4** Tightly replace the caps on the containers No. 1, No. 5 and No. 6, complete the labels on each container and place the containers back in the box.



## How To Collect Samples:

**1** Place container No. 1 – First Draw under the faucet. Turn on the COLD water and begin filling the container as if filling a glass of water. While filling container No. 1 to the designated line, grab container No. 2 and prepare to fill the next container. The water must be continuously running, and you want to try and capture all the water between samples.



**5** For containers No. 2, No. 3 and No. 4, pour these samples down your sink drain and place the empty containers back in the box.

**6** Complete the paperwork provided, place in the plastic bag and put back in the box with all sample containers.

*More instructions on the back page.*

